product name: PX-03

Adjustable ignition angle DC-CDI&COIL brief product manual

- 1. Applicable voltage:9~16V
- 2. proper temperature:-20~+40°C
- 3. Applicable ACG (generator) salient pole 10°~60° as shown in Figure 1
- 4. Applicable trigger coil polarity, as shown in Figure 2
- 5. Setting related:
 - A. Adjustable ignition angle (as shown in Figure <3>)
 - B. Adjustable ignition degree only works from 6500rpm
 - 0 scale ignition angle is 8°
 - 1 scale ignition angle is 10°
 - 2 scale ignition angle is 12°
 - And so on to the scale 9 ignition angle is 26°
 - C. The adjustable button of advance and retreat angle is shown in figure <5>

Precautions:

- 1. Do not exceed the rated voltage and temperature.
- 2. This product is a modified product. If the engine is damaged due to improper adjustment, please pay attention.
- 3. Incorrect wiring may damage the product. Please pay attention.

