

# Guang Her Cheng Electronics Industrial Co., Ltd.

No. 47-3, Chung Cheng Rd., Tahu Village, Tahuhsiang, Miaolihsien, Taiwan.

[Tel:+886-37991847](tel:+886-37991847) Fax:+886 37 991845 [www.shonceche.com](http://www.shonceche.com)

Email:ghc.sc@msa.hient.net

## Oil volume controller (full zone type) PX-51


### Instructions for use:

1. Applicable rotation speed: 300~15000rpm

2. Applicable voltage: 9-16v

3. Applicable temperature: -20°C ~+40°C

### Setting and use steps:



- The value returns to 0 and the indicator light keeps on red/green  
Turn to "1" = "Increase fuel supply time" => the indicator light is green  
Turn to "ON" = "Reduce fuel supply time" => the indicator light is red

- Turn on 1 (increasing fuel supply time) to indicate the green light, and the fuel adjustable value is (1~99)

- Turn on the 1 (reduce fuel supply time) indicating red light, and the fuel adjustable value is (1~99)

# A. 線路圖

